

## Lift Wand without Head Rest



- 1. Home button:**
  1. Close ottoman/back if open and takes the chair to a standing/entry position.
- 2. Back button:**
  1. Press left to recline back.
  2. Press right to return back to upright position.
- 3. Lift button:**
  1. Press left to lift close ottoman ,if open, and take chair to standing/entry position.
  2. Press right to take chair to seated position, if lifted, and open ottoman when chair is in seated position.

## Lift Wand with Head Rest



- 1. Home button:**
  1. Close ottoman/back if open and takes the chair to a standing/entry position.
- 2. Head Button:**
  1. Press left to open head rest.
  2. Press right to close head rest.
- 3. Back button:**
  1. Press left to recline back.
  2. Press right to return back to upright position.
- 4. Lift button:**
  1. Press left to lift close ottoman ,if open, and take chair to standing/entry position.
  2. Press right to take chair to seated position, if lifted, and open ottoman when chair is in seated position.