

# SoCozi Zero-Gravity Wand Instructions

- **Power Button:** Turns on power for massage, heat and lumbar functions.
- **Home:** Press and hold to return to all close position.
- **Massage:** Press once to turn on massage. Press again to turn off (Power button must be ON)
- **Lumbar:** Press once to inflate lumbar, press again to stop at desired location. To deflate press once more.
- **Head Buttons:** Press up arrow to open the head rest, down arrow to close head rest.
- **Footrest Buttons:** Press up arrow to open footrest, down arrow to close footrest.
- **Back Buttons:** Press down arrow to recline the chair, up arrow to close the chair
- **Memory Buttons:** With the chair at your preferred open position hold the save button for 3 sec, when the light flashes choose M1 or M2. To return to saved location press and hold the memory button that corresponds to your saved position.
- **Heat Button:** Each press of the heat button cycles through the options of 1,2, or 3 hours of heat.

